





Audio, Video and IP Intercom Systems | Bespoke Door Stations | Access Control | Sound Distribution |


CCTV and IP Cameras | Intruder Alarms | Residential & Commercial | Security Consultancy



Suardali

VEOXS

# 3 STEP GUIDE FOR MONITOR VEO XS DUOX



## LEDs

## • Red LED:

Solid when the monitor is in idle. Blinks slowly when you are in Do Not Disturb mode. **Note:** If the Do Not Disturb mode is active, you may reactivate the call by sliding the volume sliders on the right to any position other than the minimum.

## Blue LED:

You are in conversation with the door station.

## NSW (HEAD OFFICE)

(02) 9700 1700 nsw@fermaxaus.com.au

### SA OFFICE

(08) 7009 4288 sa@fermaxaus.com.au

#### QLD OFFICE

(07) 5520 2266 qld@fermaxaus.com.au

#### ACT OFFICE

(02) 6190 1555 act@fermaxaus.com.au

#### VIC OFFICE

(03) 9314 2220 vic@fermaxaus.com.au

#### NT OFFICE

(08) 7999 9162 nt@fermaxaus.com.au

#### WA OFFICE

(08) 9240 2624 wa@fermaxaus.com.au

## NZ OFFICE

(09) 337 6229 nz@fermaxnz.co.nz

